



MAGNET&FERRO FOR PANEL AND WALL SET-UP

## HOW TO PREPARE THE WALL FOR MAGNETIC COMBINATIONS

Product	Finish	Product Code	Structure	Thickness (µm)	Width (mm)	Length (m)	Pull (g/cm²)	Features	Printability
MAGNET AND FERRO SELF-ADHESIVE ROLLS   For professional applications									
MAGNET ADHESIVE	matt	MGSA-6150-BR	MAGNET brown with <b>adhesive</b>	500	615	20	28-30	to receive printed Ferro Film	-
		MGSA-6015-BR		600	615 – 1020	15	34-36		
		MGSA-10260-WM	MAGNET white <b>PVC</b> with <b>adhesive</b>		1020		28-30		
FERRO ADHESIVE		MGSF- SA-10250-BR	FERRO brown with <b>adhesive</b>	500	1020	15	-	to receive printed <u>Magnet Film</u>	
		<u>MGSF- SA-10260-WM</u>	<u>FERRO white PVC with adhesive</u>	600					

1. We highly recommend to clean wall or panel surface carefully, to ensure the best performance of the self-adhesive backing.
2. The wall or panel surface must be completely dry.
3. Use of a heat gun is recommended in order to soften the compound, revive the glued backing and improve the overall adhesion of the film to the designated surface.

